

Skyline®

Banner Stand 3000-R Exchange Graphic Replacement

Graphics are most easily changed using a two-person process

© 2003 Skyline Exhibits


PN24468




1. Remove key from bottom of base.



2. Assemble shockcorded pole and hook pole onto clip at the top of the graphic.



3. Stand on base support in back of the stand and use pole to extend graphic




4. Person 2: Place the key into the hole on the side of the base and slowly let graphic rewind until the key goes in all the way. until the plastic connecting parts pull up and out of the stand housing, and the graphic will pull no further.



5. Put pole in stand, and slide the bottom of the old graphic off of the plastic connector. Keep connecting pieces curled to slide easily.



6. Slide the bottom of the new graphic onto the plastic connector making sure the graphic is aligned on both sides.



7. Stand on the base support and use the pole to lift the new graphic up. Hold graphic taut.



8. Person 2: Remove the locking key from the base. Slowly allow the graphic to retract into the base. Replace key on base bottom.

To keep your graphic looking great, lower the graphic slowly and keep it centered – do not allow graphic to scrape the sides of the base!